

ARSON



Place contents in friction lid can and seal with evidence tape.



Liquids should be no more than 2 ml and placed in a friction lid can filled with an absorbent material.



Heat seal clothing in a bag and seal with evidence tape.

Don'ts

- Don't fill cans more than 1/2 full with a sample.
- DOT regulations prohibit mailing more than 1 oz of ignitable liquid.
- Samples must be collected in friction lid cans.
- Size of can should be proportional to the size of the sample.
- Cans should be sealed in storage until use.
- Polyester bags are to be used only for objects that will not fit into the friction lid can.
- Seal the bags with a heat sealer immediately after collection. Seal with evidence tape .
- Liquid questioned samples and liquid comparison samples should be placed into separate 2ml screw top vials.
- Place vials into friction lid can filled with an absorbent material such as cat litter or vermiculite.
- All soil samples should be frozen after proper packaging.